

Module 6: W300 x D300 x H580 mm









i) 9321400 - With Wooden Shelf ii) 9321426 - With Glass Shelf iii) 9321428 - With Wooden & Glass Shelf

PROFILE & CONNECTORS




Make top & bottom part of the cube by connecting cube profiles with connectors required as per design



Cube PLUS RTA Modules Assembly Instruction



STEP 2



Make Middle part of the cube by connecting cube profiles with connectors required as per design

STEP 3

Insert screw at all position in diagonally opposite pattern.


Note:


- Screw should be kept loose at this step
- Flatness should be maintained, it should not wobble.



STEP 4

Insert vertical profiles between Top & Middle part and Bottom & Middle part





With wooden shelf

Cube PLUS RTA Modules Assembly Instruction



STEP 5

Insert screw at all position & tight all the screw present in cube in diagonally opposite pattern and put the cover caps for concealing the screws.


Note:

- Screw should not be over tightened
- Screw should be kept little loose to maintain flatness & should be fitted in diagonally opposite pattern
- > Flatness should be maintained, it should not wobble




STEP 6

- Drill on wall as per drilling dimension given
- ▶ Fix Wall Mounting Bracket using Wall screw & Plug
- Hang the structure on brackets & do height adjustment if required



Cube PLUS RTA Modules Assembly Instruction





Maximum weight capacity

